

Interactive Panaboard Software Revision History (27/March/2013)  
for UB-8325  
(c) Panasonic System Networks Co., Ltd. 2001-2013.

Interactive Panaboard Software

| Ver. | Changing issue(s) / Fixing problem(s)   | Note  |
|------|---|---|
| 5.30 | 1. Added Windows Vista 64bit edition as support OS<br>2. Added Windows 7 32bit & 64bit edition as support OS  | Version for Windows 7. Windows 8 is supported.                  |
| 5.10 | 1. Added the function that menu can be opened by clicking the icon of notification area.<br>2. (Fix)<br>1) The arrow and pen might not be able to be switched.<br>2) The icon of the Drawing Tool might not be able to be selected after launching original keyboard in Windows Vista.  |   |
| 5.00 | 1.Changing for Windows Vista 32bit.   | Version for Windows Vista 32bit                                 |
| 4.10 | 1. Supported PowerPoint 2007.<br>2. (Fix) An error appeared in recording in the projector mode.   | Version for Windows 98 / Windows Me / Windows 2000 / Windows XP |
| 4.01 | 1. Corresponded to Russian language.  |   |
| 4.00 | 1. Supported USB I/F (USB IF for UB-8325, RS-232-C I/F for KX-BP800).<br>2. If Interactive Panaboard and a projector are fixed not to move, Calibration operation can be skipped when starting Interactive Panaboard Software.<br>3. When a marker is selected in Desktop Drawing Tool, the Tool can be disappeared temporarily.<br>4. (UB-8325 only)<br>In Whiteboard mode, a new page can be added or the current page can be switched in last 2 pages by pressing Advance Key.<br>5. (UB-8325 only)<br>Desktop image (projected image) can be printed by pressing the Copy Key on Interactive Panaboard. | This version can work both with UB-8325 and KX-BP800.           |
| 3.02 | 1. Added the function that displays the version of program files (EXE/DLL) on [About] menu<br>2. Added the uninstallation shortcut to the [Interactive Panaboard] menu<br>3. (Fix)<br>When Interactive Panaboard Software (Ver3.01) is installed without Uninstall  |   |
| 3.01 | 1. Corresponded to Chinese language.<br>*This correspondence does not affect the use in the other languages' Windows OS.<br>2. (Fix)<br>1) In case of Windows Server 2003, "Windows Keyboard" can not be selected in the Options dialog box.<br>2) Minus value can be input in the "automatic save interval" box in the File Settings dialog.   |   |
| 3.00 | 1. Added Handwriting Recognition function<br>2. Added PowerPoint Control function<br>3. Corresponded to multi-page TIFF   |   |
| 2.00 | 1. Added On-Screen Keyboard function<br>2. (Fix)<br>In projector mode, some unexpected drawings appear near the buttons that have been clicked before when using a marker on Desktop Drawing tool.  |   |

|      |   |  |
|------|---|--|
| 1.10 | <ol style="list-style-type: none"> <li>Added continuous playback of all pages<br/>Pages from 1 through last can be played continuously.</li> <li>Added Highlight marker<br/>The lower image is visible when the Highlight marker is used.</li> <li>Updated Marker/Eraser setting dialog<br/>Added Scroll Bar to set a marker width easily.<br/>Added Check Box to set the Same width for black, red, blue and green markers at once.</li> <li>Added shortcut icons for Print Preview, Undo and Redo menus to the Main Toolbar.</li> <li>(Fix)<br/>In the Whiteboard mode, when the eraser color is set to some color other than white, the eraser does not erase drawings but draws the color.</li> </ol> |  |
| 1.01 | <ol style="list-style-type: none"> <li>Corresponded to 3 languages<br/>The language is decided by the setting of the Windows automatically.<br/>English, German and Japanese.</li> </ol>  |  |
| 1.00 | <ol style="list-style-type: none"> <li>First Release<br/>English only.</li> </ol>   |  |

#### TWAIN Driver

| Ver. | Changing issue(s) / Fixing problem(s)  | Note  |
|------|--|---|
| 3.00 | <ol style="list-style-type: none"> <li>Added Windows Vista 64bit edition as support OS</li> <li>Added Windows 7 32bit &amp; 64bit edition as support OS</li> </ol> | Version for Windows 7.<br>Windows 8 is supported. |
| 2.00 | <ol style="list-style-type: none"> <li>Changing help to HTML Help format.</li> </ol>   | Version for Windows Vista 32bit                   |
| 1.00 | <ol style="list-style-type: none"> <li>First Release</li> </ol>  |   |

#### Printer Driver

| Ver. | Changing issue(s) / Fixing problem(s)  | Note  |
|------|--|---|
| 3.00 | <ol style="list-style-type: none"> <li>Added Windows Vista 64bit edition as support OS</li> <li>Added Windows 7 32bit &amp; 64bit edition as support OS</li> </ol> | Version for Windows 7.<br>Windows 8 is supported. |
| 1.00 | <ol style="list-style-type: none"> <li>First Release</li> </ol>  |   |

#### Board Image Capture

| Ver. | Changing issue(s) / Fixing problem(s)  | Note  |
|------|--|---|
| 3.40 | <ol style="list-style-type: none"> <li>Added Windows Vista 64bit edition as support OS</li> <li>Added Windows 7 32bit &amp; 64bit edition as support OS</li> </ol> | Version for Windows 7.<br>Windows 8 is supported. |
| 3.30 | <ol style="list-style-type: none"> <li>(Fix) Scan Image cannot be save to root folder.</li> </ol>  |   |
| 3.00 | <ol style="list-style-type: none"> <li>First Release</li> </ol>  |   |

#### PC Installer

| Ver. | Changing issue(s) / Fixing problem(s)   | Note                            |
|------|---|---------------------------------|
| 2.20 | <ol style="list-style-type: none"> <li>Added Windows 8 32bit &amp; 64bit edition as support OS</li> </ol>   | Version for Windows 8           |
| 2.10 | <ol style="list-style-type: none"> <li>(Fix) Interactive Panaboard Software might not be able to be launched when the USB cable connect to the board with your computer.</li> </ol> |                                 |
| 2.00 | <ol style="list-style-type: none"> <li>Changing for Windows Vista 32bit.</li> </ol>   | Version for Windows Vista 32bit |
| 1.00 | <ol style="list-style-type: none"> <li>First Release</li> </ol>   |                                 |

## **Notes of Software Installation on Windows Vista / Windows 7 / Windows 8**

1. If the User Account Control window is displayed, select [Allow].
  2. If the Windows Security window is displayed, select [Install].
- When connecting the USB cable to your computer, the wizard window is not displayed in Windows Vista / Windows 7 / Windows 8.

\* Microsoft, Windows and Windows Vista are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

\* All other trademarks identified herein are the property of their respective owners.