Difference of Configuration Parameters between TGP and UT1

NO.03-006

September 30, 2011

Ver.1.0

Panasonic Corporation

1.Abstract about this document

This document describe difference point of configuration parameter between TGP and UT1.

2.Revision history

Date	Version	Revision
Sep.30, 2011	Ver. 1.0	Initial Release

Item	onfiguration parameters. Sub Item	TGP	UT1	Note(reason)
	oub item			Changed.
Top keywords	-	# PCC Standard Format File #	# Panasonic SIP Phone Standard Format File #	Both new and old format are acceptable.
System Settings	System Time Settings Syslog Settings		LOCAL_TIME_ZONE_POSIX=" SYSLOG_RTPSMLY_INTVL_1="20"	Added TR-106 related parameter.
	Sysiog Settings		SYSLOG_RTPSMLY_INTVL_2="20"	
			# UT133/UT136 Only	Added for more informations.
			SYSLOG_RTPSMLY_INTVL_3="20" SYSLOG_RTPSMLY_INTVL_4="20"	
	Firmware Upgrade Settings	FIRM_VER_EUDECT="00.00"	FIRM_VERSION="01.000"	Changed because UT has no DECT h/s.
	Management Server Settings	FIRM_VER_USDECT="00.00"	ACS_URL="	Minor version digits are expanded from 2 to 3 in UT.
	Management Server Settings		ACS_URL="" ACS_USER_ID=""	
			ACS_PASS=""	
			PERIODIC_INFORM_ENABLE="N" PERIODIC_INFORM_INTERVAL="86400"	Added TR-069 relateed parameters.
			PERIODIC INFORM TIME="0001-01-01T00:00:00Z"	
			CON REQ USER ID=""	
Telephone Settings	Multi Number Settings		CON_REQ_PASS="	
relephone Settings	muit rumber Jettings	INCOMING_CALL_GROUP_1="1,1,1,1,1,1,1" OUTGOING_CALL_LINE_HS1="1,1,1,1,1,1,1"		
		OUTGOING_CALL_LINE_HS2="1,1,1,1,1,1,1" OUTGOING_CALL_LINE_HS2="1,1,1,1,1,1,1"		
		OUTGOING_CALL_LINE_HS3="1,1,1,1,1,1,1,1"		
		OUTGOING_CALL_LINE_HS4="1,1,1,1,1,1,1,1" OUTGOING_CALL_LINE_HS5="1,1,1,1,1,1,1,1"		
		OUTGOING_CALL_LINE_HSS= 1,1,1,1,1,1,1 OUTGOING_CALL_LINE_HSS="1,1,1,1,1,1,1"		
		OUTGOING_CALL_LINE_BS="1,1,1,1,1,1,1"		Deleted because UT has no DECT h/s.
		DEFAULT_LINE_SELECT_HS1="1,0,0,0,0,0,0,0" DEFAULT_LINE_SELECT_HS2="1,0,0,0,0,0,0,0"		
		DEFAULT LINE SELECT HS3="1.0.0.0.0.0.0.0"		
		DEFAULT_LINE_SELECT_HS4="1,0,0,0,0,0,0,0"		
		DEFAULT_LINE_SELECT_HS5="1,0,0,0,0,0,0,0" DEFAULT_LINE_SELECT_HS6="1,0,0,0,0,0,0"		
		DEFAULT_LINE_SELECT_BS="1,0,0,0,0,0,0,0"		
	Call Control Settings	CONFERENCE_SERVER_ADDRESS="conference@example.com" EMERGENCY_CALL1="911"	CONFERENCE_SERVER_URI="conference@example.com"	Changed.
	_	EMERGENCY_CALL1='911"		
		EMERGENCY_CALL2=" EMERGENCY_CALL3="		Deleted because UT has no DECT h/s.
		EMERGENCY CALL4=""		Use Dial Plan setting as an alternative method.
		EMERGENCY_CALL5=""		
			MACRODIGIT_TIM="5"	Added.
			COUNTRY_CALLING_CODE="" NATIONAL_ACCESS_CODE=""	Added.
			NATIONAL_ACCESS_CODE="	Added.
			DATA_LINE_MODE="N" NUM_PLAN_PICKUP_DIRECT=""	Added. Added.
			TALK PACKAGE="N"	Added.
			HOLD_PACKAGE="N" HOLD_RECALL_TIM="60"	Added.
			AUTO_ANS_RING_TIM="5"	Added. Added.
			RINGING_OFF_SETTING_ENABLE="Y"	Added.
			AUTO_CALL_HOLD="N" REDIALKEY CALLLOG ENABLE="N"	Added.
			ONHOOK_TRANSFER_ENABLE="Y"	Added.
			DISCONNECTION_MODE="1"	Added.
			TONE_LEN_DISCONNECT_HANDSET="10" TONE_LEN_DISCONNECT_HANDSFREE="3"	Added.
			KEY_PAD_TONE="Y"	Added.
	Tone Settings		DIAL_TONE1_FRQ="350,440"	
			DIAL_TONE1_GAIN="0" DIAL_TONE1_RPT="0"	
		DIAL_TONE_FRQ="350,440"	DIAL_TONE1_TIMING="60,0"	Expanded for more flexibility. If the FWD/DND features are set,DIALTONE_2 * are used.
		DIAL_TONE_TIMING="0,0,0,0"	DIAL_TONE2_FRQ="350,440"	If the FWD/ DND reatures are set, DIACTONE_2,* are used.
			DIAL_TONE2_GAIN="0" DIAL_TONE2_RPT="0"	
			DIAL_TONE2_TIMING="60,0"	
			BUSY_TONE_GAIN="0" BUSY_TONE_RPT="1"	Expanded for more flexibility.
		BUSY_TONE_TIMING="500,500,500"	BUSY_TONE_TIMING="60,500,440"	Changed initial value.
			RINGBACK_TONE_GAIN="0"	Expanded for more flexibility.
		RINGING_TONE_TIMING="2000,4000,2000,4000"	RINGBACK_TONE_RPT="1" RINGBACK_TONE_TIMING="60,2000,3940"	Changed initial value.
			DIAL_TONE4_FRQ="350,440"	+
		STT_TONE_FRQ="350,440"	DIAL_TONE4_FRQ="350,440" DIAL_TONE4_GAIN="0"	Expanded for more flexibility.
		STT_TONE_TIMING="100,100,100,100,100,100,100,100,100,100	DIAL_TONE4_RPT="0"	Changed initial value.
			DIAL_TONE4_TIMING="560,100,100,100,100,100,100,100,100,100,1	<u> </u>
			REORDER_TONE_GAIN="0"	Expanded for more flexibility.
		REORDER_TONE_TIMING="250,250,250,250,250,250,250,250,250"	REORDER_TONE_RPT="1" REORDER_TONE_TIMING="60,250,190"	Changed initial value.
		HOWLER_TONE_FRQ="1400,2060"		
		HOWLER_TONE_TIMING="100,100,100,100"		Howler Function was deleted in UT. UT will become idle after timeout.
		HOWLER_START_TIME='30"	HOLD ALARM FRO="425"	+
			HOLD ALARM GAIN="0"	Add Section States
			HOLD_ALARM_RPT="1"	Added for more flexibility.
			HOLD_ALARM_TIMING="120,14880" CW TONE1 FRQ="425"	
			CW_TONE1_GAIN="0"	Add for the first the
			CW_TONE1_RPT="1"	Added for more flexibility.
			CW_TONE1_TIMING='120,120,120,120,120,14400" HOLD_TONE_FRQ='425"	+
			HOLD_TONE_GAIN="0"	Added for more flexibility.
			HOLD_TONE_RPT="1"	Added for more flexibility.
			HOLD_TONE_TIMING="500,190,190,190,2890"	

Item	Sub Item	TGP	UT1	Note(reason)
Telephone Settings	Telephone Settings		DISPLAY_NAME_REPLACE="Y"	Added for more flexibility. Keep default usually.
			NUMBER_MATCHING_LOWER_DIGIT="7" NUMBER_MATCHING_UPPER_DIGIT="10"	Added for more flexibility.
			DISPLAY_DATE_PATTERN="0" DISPLAY_TIME_PATTERN="0"	Added for more flexibility.
			DEFAULT_LANGUAGE="en-US"	
			EXTENSION_PIN="0000000000"	Added for display lock function in UT.
			POUND_KEY_DELIMITER_ENABLE="Y"	Added for more flexibility.
	Miscellaneous Telephone Settings		ADJDATA_GAIN="	Added for more flexibility. Added for more flexibility. Keep default usually.
	Flexible Button Settings(KX-UT133/KX- UT136only)		FIEX BUTTON JACILITY_ACTI="X, PANASONIC_IPTEL_DN" FIEX, BUTTON JACILITY_AGGI="1" FIEX, BUTTON JOICK, DIAL1=" FIEX, BUTTON JOICK, DIAL1=" FIEX, BUTTON JACILITE-DN01"	
			FIEX_BUTTON_FACILITY_ACT24="X_PANASONIC_IPTEL_HEADSET" FLEX_BUTTON_FACILITY_ARG24=" FLEX_BUTTON_QUICK_DIAL24=" FLEX_BUTTON_LABEL24=" FLEX_BUTTON_LABEL24="	Added for UT13x.
VoIP Settings	Codec Settings		INBANDDTMF_VOL="-5"	
	•		DTMF_SIGNAL_LEN='180' DTMF_INTDIGIT_TIM='90'	Added for more flexibility. Keep default usually.
Line Settings	Call Control Settings		RETURN_VOL_SET_DEFAULT_ENABLE="N"	Added for more flexibility. Keep default usually.
ĺ			FLASH_RECALL_TERMINATE="Y"	Added for more flexibility. Keep default usually.
	SIP Settings		FLASHHOOK_CONTENT_TYPE="Signal" SIP_RESPONSE_CODE_DND='403'	Added for more flexibility. Keep default usually. Added for more flexibility. Keep default usually.
ĺ	on odunys		SIP_RESPONSE_CODE_DND= 403 SIP_RESPONSE_CODE_CALL_REJECT='603"	Added for more flexibility. Keep default usually. Added for more flexibility. Keep default usually.
Line(n) Settings	VoIP Settings	SDP_CODECO_n="G722" SDP_CODECO_n="G722" SDP_CODECO_n="G726-82" SDP_CODECO_n="G726-82" SDP_CODECO_n="G726-82" SDP_CODECO_n="G726-82" SDP_CORTEO_n="B000" SDP_CKRITES_n="B000" SDP_CKRITES_n="	CODEC_ENABLE_0_n='Y' (G722) CODEC_ENABLE_1_n='Y' (PCMA) CODEC_ENABLE_2_n='Y' (G72832) CODEC_ENABLE_3_n='Y' (G7284) CODEC_ENABLE_4_n='Y' (G7284) CODEC_ENABLE_4_n='Y' (G7284) CODEC_ENGLE_4' (G7284)	Simplified setting to correspondence to TR069 features. Please use Line Setting(n)-Volp Setting parameter mentioned below Changed.
			RTCP_ENABLE_n="N" RTCP_SEND_BY_SDP_n="0" RTP_CLOSE_ENABLE_n="V"	Added for more flexibility. Keep default usually.
	Call Control Settings	TELEVENT_PTYPE_n="101" SYNCHRONIZATION_ENABLE_n="N"	TELEVENT_PAYLOAD="101" FWD_DND_SYNCHRO_ENABLE_n="N"	Changed Changed.
	Can Control Settings	OTHORIZATION_CHADLE_ITE IN	RESOURCELIST_URI_n=""	Added, For BLF feature.
ĺ			CW_ENABLE_n="Y"	· · · · · · · · · · · · · · · · · · ·
	SIP Settings	SHARED_USER_ID_n="1234567890a" LINE_ID_n="	SIP_URI_n=*"	Unified to SIP_URI in UT.
ĺ			LINE_ENABLE_n="Enabled"	Added for more flexibility. Keep default usually.
ĺ			PROFILE_ENABLE_n="Enabled"	Added for more flexibility. Keep default usually.
ĺ		TOS SIP n="0"	SIP_SESSION_METHOD_n="0" DSCP_SIP_n="0"	Added for more flexibility. Keep default usually.
		I UO_OIF_II= U	SIP TIMER T4 n="0"	Changed. Added for more flexibility. Keep default usually.
ĺ		INVITE_RTXN_n="6"		Changed to SIP_TIMER_*
ĺ		OTHER_RTXN_n="10"		Changed to SIP_TIMER_*
			SIP_REFRESHER_n="0"	Added for more flexibility. Keep default usually.
			SIP_ADD_RPORT_n="N"	Added for more flexibility. Keep default usually. Added for more flexibility. Keep default usually.
			ADD_TRANSPORT_UDP_n="N"	Added for more flexibility. Keep default usually.
			ADD_EXPIRES_HEADER_n="Y"	Added for more flexibility. Keep default usually.
			SIP_HOLD_HOLDRECEIVE_n="Y"	Added for more flexibility. Keep default usually.
			SIP_ADD_DIVERSION_n="1"	Added for more flexibility. Keep default usually.

NOTE: Please refer to the Administrator Guide for more information of each parameters.

Other parameters that doesn't exist in the above-mentioned are basically common in TGP and UT1.