

Parameter List

(KX-UDS/UDT series)

No.43-003

Oct. 9, 2012

Ver 1.0

Panasonic Corporation

Abstract

1.About this document

This document lists all parameters in UDS/UDT provided by either WEB or a configuration file, or both.

2.Revision history

Date	Version	Revision	Firmware version
Oct. 9, 2012	ver 1.0	Initial Release	01.002

Parameter List

Note:

*1 This setting can also be configured through phone user interface programming.

*2 Chapter number in Administrator guide of Web User Interface Programming

*3 Chapter number in Administrator guide of Configuration File Programming

WEB Settings				Configuration File			
	Menu Item	Section Title	Chapter number(*2)	Parameter in the Web Setting	Parameter in a Configuration File	Chapter number(*3)	
Status	Version Information	CS Version Information	2.2.1.1	Model			
				Operating BANK			
				IPL Version			
				Firmware Version			
		PS Version Information (Model PS Version Information (Model PS Version Information (Model PS Version Information (Model	2.2.1.2	2.2.1.3	Model		
					Firmware Version		
					Model		
					Firmware Version		
	Network Status	Network Status	2.2.2.1	MAC Address			
				Ethernet Link Status (LANPort)			
				Connection Mode			
				IP Address			
				Subnet Mask			
				Default Gateway			
				DNS1			
				DNS2			
	CS Version List	CS Version List	2.2.3.1	Air Sync Group			
				CS Name			
				CS ID			
				MAC Address			
	CS Information	CS Information	2.2.4.1	Firmware Version			
				Air Sync Group			
				CS Name			
				CS ID			
PS Information	PS Information	2.2.5.1	MAC Address				
			Status				
			Path 1-16				
			Regist PS Number				
PS VoIP Status	PS VoIP Status	2.2.6.1	No.				
			PS Name	PROFILE_NAME_PSy	4.6.2		
			Location CS Name				
			Location CS MAC				
PS Information	PS Information	2.2.5.1	Model				
			Firmware Version				
			Phonebook Import Time [Result]				
			No.				
PS VoIP Status	PS VoIP Status	2.2.6.1	PS Name	PROFILE_NAME_PSy	4.6.2		
			Phone Number	PHONE_NUMBER_PSy_n	4.6.2		
			VoIP Status				
			No.				
Network	Basic Network Settings	Connection Mode	2.3.1.1	Connection Mode	CONNECTION_TYPE	4.3.1	
				DHCP Settings	2.3.1.2	Host Name	HOST_NAME
		Static Settings	2.3.1.3	Domain Name Server	DHCP_DNS_ENABLE	4.3.1	
				Static IP Address	STATIC_IP_ADDRESS	4.3.1	
				Subnet Mask	STATIC_SUBNET	4.3.1	
				Default Gateway	STATIC_GATEWAY	4.3.1	
				DNS1	USER_DNS1_ADDR	4.3.1	
				DNS2	USER_DNS2_ADDR	4.3.1	
		DNS Settings (This item is not in web setting)	-		DNS_QRY_PRL	4.3.2	
					DNS_PRIORITY	4.3.2	
					DNS1_ADDR	4.3.2	
					DNS2_ADDR	4.3.2	
	Ethernet Port Settings	Link Speed/Duplex Mode	2.3.2.1	LAN Port			
				Enable VLAN	VLAN_ENABLE	4.3.3	
		VLAN Settings	2.3.2.2	IP Phone			
				VLAN ID	VLAN_ID_IP_PHONE	4.3.3	
	HTTP Client Settings	HTTP Client Settings	2.3.3.1	Priority	VLAN_PRI_IP_PHONE	4.3.3	
					HTTPD_PORTOPEN_AUTO	4.3.4	
					HTTP_VER	4.3.4	
					HTTP_USER_AGENT	4.3.4	
		Proxy Server Settings	2.3.3.2		HTTP_SSL_VERIFY	4.3.4	
					CFG_ROOT_CERTIFICATE_PATH	4.3.4	
				Enable Proxy			
				Proxy Server Address			
HTTP Authentication	HTTP Authentication	2.3.4.1	Proxy Server Port				
			Authentication ID				
Global Address Detection	Global Address Detection	2.3.5.1	Authentication Password				
			Detection Method				
	STUN Server	2.3.5.2	Detection Interval				
			STUN Server Address	STUN_SERV_ADDR	4.3.6		
		STUN Server Port	STUN_SERV_PORT	4.3.6			
			STUN_2NDSERV_ADDR	4.3.6			
			STUN_2NDSERV_PORT	4.3.6			

WEB Settings				Configuration File				
Menu Item	Section Title	Chapter number(*2)	Parameter in the Web Setting	Parameter in a Configuration File	Chapter number(*3)			
System	Web Language	Web Language	2.4.1.1	Language				
	Administrator Password	Change Administrator Password	2.4.2.1	Current Password	ADMIN_PASS	4.2.1		
				New Password	ADMIN_PASS	4.2.1		
				Confirm New Password	ADMIN_PASS	4.2.1		
					ADMIN_ID	4.2.1		
	Change User Password	[PS tab screen]						
		Change User Password	2.4.3.1	No.				
				PS Name	PROFILE_NAME_PSy	4.6.2		
				Phone Number	PHONE_NUMBER_PSy_n	4.6.2		
		Change User Password	[PS select screen]					
			Change User Password	2.4.3.3	PS Name	PROFILE_NAME_PSy	4.6.2	
	Change User Password				USER_PASS_PSy	4.2.1		
	Change User Password	2.4.3.4	Confirm New Password	USER_PASS_PSy	4.2.1			
	Web Server Settings	Web Server Settings	2.4.4.1	Web Server Port				
	Time Setting	Time Setting	2.4.5.1	Port Close Timer				
				Date				
				Date				
				Month				
				Year				
				Time				
				Hour				
	Time Adjust Settings	Synchronization	2.4.6.1	Enable Synchronization by NTP				
				Synchronization Interval	TIME_QUERY_INTVL	4.3.5		
					TIME_SYNC_INTVL	4.3.5		
		Time Server	2.4.6.2	NTP Server Address	NTP_ADDR	4.3.5		
		Time Zone	2.4.6.3	Time Zone	TIME_ZONE	4.2.2		
					LOCAL_TIME_ZONE_POSIX	4.2.2		
		Daylight Saving Time (Summer Time)	2.4.6.4	Enable DST (Enable Summer Time)*1	DST_ENABLE	4.2.2		
				DST Offset (Summer Time Offset)	DST_OFFSET	4.2.2		
				Start Day and Time of DST (Start Day and Time of Summer Time)	2.4.6.5	Month	DST_START_MONTH	4.2.2
						Day of Week	DST_START_ORDINAL_DAY	4.2.2
							DST_START_DAY_OF_WEEK	4.2.2
				End Day and Time of DST (End Day and Time of Summer Time)	2.4.6.6	Time	DST_START_TIME	4.2.2
	Month	DST_STOP_MONTH	4.2.2					
	Day of Week	DST_STOP_ORDINAL_DAY	4.2.2					
				DST_STOP_DAY_OF_WEEK	4.2.2			
				DST_STOP_TIME	4.2.2			
	CS Name	CS Name	2.4.7.1	Name	PROFILE_NAME_CS	4.6.2		
	Air Settings	Air Sync Group	2.4.8.1	Air Sync Group	WL_AIRSYNGROUP_CS	4.4.4		
		CS Class	2.4.8.2	CS Class	WL_CLASS_CS	4.4.4		
		Super Master CS IP Address	2.4.8.3	IP Address	SUPERMASTER_IPADDRESS_CS	4.4.4		
		Other Settings (This item is not in web setting)	-		HO_RTP_PORT_MIN	4.4.4		
					HO_RTP_PORT_MAX	4.4.4		
					HO_EXE_TIME	4.4.4		
	CS Management	CS Registration	2.4.9.1	Air Sync Group				
		CS Registration List	2.4.9.2	No.				
				Index				
CS Name								
CS ID								
MAC Address								
IP Address								
Tree Survey	Tree Survey	2.4.10.1	Air Sync Group					
	Survey List	2.4.10.2	Index					
			CS Name					
			MAC Address					
			CS Class					
			Status					
			Primary CS Index					
			Secondary CS Index					
			Level					
CS Monitor	CS Monitor	2.4.11.1	Air Sync Group					
			Index					
			RSSI					
			Error Rate					
			Wired LAN					
			CS Name					
			MAC Address					
			Status					
			Current Sync CS					
			CS Type					
			CS RPT					
			CS Index					
PS Registration	[PS tab screen]							
	PS Registration	2.4.12.1	No.					
			PS Name	PROFILE_NAME_PSy	4.6.2			
			Phone Number	PHONE_NUMBER_PSy_n	4.6.2			
			Wireless Status					
PS Registration -PS Settings	PIN Code	2.4.15.1	PIN Code*2	WL_PSREGISTRATION_PIN	4.4.4			

WEB Settings				Configuration File		
Menu Item	Section Title	Chapter number(*2)	Parameter in the Web Setting	Parameter in a Configuration File	Chapter number(*3)	
VoIP	SIP Settings	SIP Setting	2.5.1.1	SIP User Agent	SIP_USER_AGENT	4.6.2
		SIP Server	2.5.1.2	Registrar Server Address	SIP_RGSTR_ADDR	4.6.2
				Registrar Server Port	SIP_RGSTR_PORT	4.6.2
				Proxy Server Address	SIP_PRXY_ADDR	4.6.2
				Proxy Server Port	SIP_PRXY_PORT	4.6.2
				Presence Server Address	SIP_PRSNC_ADDR	4.6.2
				Presence Server Port	SIP_PRSNC_PORT	4.6.2
		Outbound Proxy Server	2.5.1.3	Outbound Proxy Server Address	SIP_OUTPROXY_ADDR	4.6.2
		SIP Service Domain	2.5.1.4	Outbound Proxy Server Port	SIP_OUTPROXY_PORT	4.6.2
		DNS	2.5.1.5	Service Domain	SIP_SVCDOMAIN	4.6.2
				Enable DNS SRV lookup	SIP_DNSSRV_ENA	4.6.2
				SRV lookup Prefix for UDP	SIP_UDP_SRV_PREFIX	4.6.2
		Transport Protocol of SIP	2.5.1.6	SRV lookup Prefix for TCP	SIP_TCP_SRV_PREFIX	4.6.2
				Transport Protocol	SIP_TRANSPORT	4.6.2
		Timer Settings	2.5.1.7	T1 Timer	SIP_TIMER_T1	4.6.2
				T2 Timer	SIP_TIMER_T2	4.6.2
				Timer B	SIP_TIMER_B	4.6.2
				Timer D	SIP_TIMER_D	4.6.2
				Timer F	SIP_TIMER_F	4.6.2
				Timer H	SIP_TIMER_H	4.6.2
				Timer J	SIP_TIMER_J	4.6.2
					SIP_TIMER_T4	4.6.2
			REG_EXPIRE_TIME	4.6.2		
			REG_INTERVAL_RATE	4.6.2		
		Quality of Service (QoS)	2.5.1.8	SIP Packet QoS (DSCP)	DSCP_SIP	4.6.2
		SIP extensions	2.5.1.9	Supports 100rel (RFC 3262)	SIP_100REL_ENABLE	4.6.2
				Supports Session Timer (RFC4028)	SIP_SESSION_TIME	4.6.2
		Security	2.5.1.10	Enable SSAF (SIP Source Address Filter)	SIP_DETECT_SSAF	4.6.2
					SIP_RCV_DET_HEADER	4.6.2
		other settings	-		SIP_2NDPROXY_ADDR	4.6.2
					SIP_2NDPROXY_PORT	4.6.2
					SIP_2NDRGSTR_ADDR	4.6.2
					SIP_2NDRGSTR_PORT	4.6.2
					SIP_FOVR_NORSP	4.6.2
					SIP_FOVR_MAX	4.6.2
					SIP_18X_RTX_INTVL	4.6.2
					SIP_2NDPRSNC_ADDR	4.6.2
					SIP_2NDPRSNC_PORT	4.6.2
					USE_DEL_REG_OPEN	4.6.2
					PORT_PUNCH_INTVL	4.6.2
					SIP_SUBS_EXPIRE	4.6.2
					SUB_RTX_INTVL	4.6.2
					REG_RTX_INTVL	4.6.2
					SIP_P_PREFERRED_ID	4.6.2
					SIP_PRIVACY	4.6.2
					ADD_USER_PHONE	4.6.2
					SDP_USER_ID	4.6.2
					SUB_INTERVAL_RATE	4.6.2
					SIP_ANM_DISPNAME	4.6.2
					SIP_ANM_USERNAME	4.6.2
					SIP_ANM_HOSTNAME	4.6.2
					SIP_CONTACT_ON_ACK	4.6.2
					SIP_SESSION_METHOD	4.6.2
					SIP_REFRESHER	4.6.2
					SIP_INVITE_EXPIRE	4.6.2
					SIP_ADD_RPORT	4.6.2
					SIP_REQURI_PORT	4.6.2
	ADD_TRANSPORT_UDP			4.6.2		
	ADD_EXPIRES_HEADER			4.6.2		
	SIP_HOLD_HOLDRECEIVE			4.6.2		
	SIP_ADD_DIVERSION			4.6.2		
	SIP_RESPONSE_CODE_DND			4.6.2		
	SIP_RESPONSE_CODE_CALL_REJECT			4.6.2		
	SIP_REGI_PS_LIMIT	4.2.6				
	CSL_PC_LISTEN_PORT	4.6.2				
SIP Settings -PS	[PS tab screen]	-	No.			
	SIP Settings	2.5.2.1	PS Name	PROFILE_NAME_PSy	4.6.2	
			Line No.			
			Phone Number	PHONE_NUMBER_PSy_n	4.6.2	
	[PS select screen]	-				
	PS Name	2.5.3.1	PS Name	PROFILE_NAME_PSy	4.6.2	
			Phone Number	PHONE_NUMBER_PSy_n	4.6.2	
	Phone Number	2.5.3.2	SIP URI	SIP_URI_PSy_n	4.6.2	
				LINE_ENABLE_PSy_n	4.6.2	
				PROFILE_ENABLE_PSy	4.6.2	
		PROFILE_NAME_PSy	4.6.2			
SIP Authentication	2.5.3.3	Authentication ID	SIP_AUTHID_PSy_n	4.6.2		
		Authentication Password	SIP_PASS_PSy_n	4.6.2		
SIP Source Port	2.5.3.4	Source Port	SIP_SRC_PORT_PSy_n	4.6.2		
Other Settings	-		IPEI_PSy	4.2.6		

WEB Settings				Configuration File				
Menu Item	Section Title	Chapter number(*2)	Parameter in the Web Setting	Parameter in a Configuration File	Chapter number(*3)			
VoIP	VoIP Settings	RTP Settings	RTP Packet Time	RTP_PTIME	4.5.2			
			Minimum RTP Port Number	RTP_PORT_MIN	4.5.2			
			Maximum RTP Port Number	RTP_PORT_MAX	4.5.2			
				RTCP_SEND_BY_SDP	4.5.2			
				RTP_CLOSE_ENABLE	4.5.2			
			Telephone-event Payload Type	TELEVENT_PAYLOAD	4.5.3			
		Quality of Service (QoS)	2.5.4.2	RTP Packet QoS(DSCP)	DSCP_RTP	4.5.2		
					DSCP_RTCP	4.5.2		
		Statistical Information	2.5.4.3	RTCP Enable	RTCP_ENABLE	4.5.2		
				RTCP Interval	RTCP_INTVL	4.5.2		
		Jitter Buffer	2.5.4.4	Maximum Delay	MAX_DELAY	4.5.2		
				Minimum Delay	MIN_DELAY	4.5.2		
				Initial Delay	NOM_DELAY	4.5.2		
		DTMF	2.5.4.5	DTMF Type	OUTBANDDTMF	4.5.3		
					DTMF_RELAY	4.5.3		
					INBANDDTMF_VOL	4.5.3		
					DTMF_SIGNAL_LEN	4.5.3		
					DTMF_INTDIGIT_TIM	4.5.3		
		Call Hold	2.5.4.6	Supports RFC 2543 (c=0.0.0.0)	OUTBANDDTMF_VOL	4.5.3		
				Supports RFC 2543 (c=0.0.0.0)	RFC2543_HOLD_ENABLE	4.5.3		
		CODEC Preferences	2.5.4.7	G722				
				Enable	CODEC_ENABLEx	4.5.1		
				Priority	CODEC_PRIORITYx	4.5.1		
				PCMA				
				Enable	CODEC_ENABLEx	4.5.1		
				Priority	CODEC_PRIORITYx	4.5.1		
				G726-32				
				Enable	CODEC_ENABLEx	4.5.1		
				Priority	CODEC_PRIORITYx	4.5.1		
				G729A				
				Enable	CODEC_ENABLEx	4.5.1		
				Priority	CODEC_PRIORITYx	4.5.1		
				PCMU				
				Enable	CODEC_ENABLEx	4.5.1		
				Priority	CODEC_PRIORITYx	4.5.1		
				CODEC_G711_REQ	4.5.1			
				CODEC_G729_PARAM	4.5.1			
		Telephone	Call Control	[Common tab screen]	-			
				Call Control	2.6.1.1	Send SUBSCRIBE to Voice	VM_SUBSCRIBE_ENABLE	4.4.1
						Mail Server		
						Conference Server URI	CONFERENCE_SERVER_URI	4.4.1
Inter-digit Timeout	INTDIGIT_TIM					4.4.1		
Timer for Dial Plan	MACRODIGIT_TIM					4.4.1		
International Call Prefix	INTERNATIONAL_ACCESS_CODE					4.4.1		
Country Calling Code	COUNTRY_CALLING_CODE					4.4.1		
National Access Code	NATIONAL_ACCESS_CODE					4.4.1		
Flash/Recall Button	FLASH_RECALL_TERMINATE					4.6.1		
Flash Hook Event	FLASHHOOK_CONTENT_TYPE					4.6.1		
	VOICE_MESSAGE_AVAILABLE					4.6.1		
	HOLD_SOUND_PATH					4.6.1		
	HOLD_RECALL_TIM					4.4.1		
	AUTO_CALL_HOLD					4.4.1		
	DISCONNECTION_MODE					4.4.1		
	PHONE_LEN_DISCONNECT_HANDSFREE			4.4.1				
	FIRSTDIGIT_TIM			4.4.1				
Call Rejection Phone Numbers	2.6.1.2			1-30				
[PS tab screen]				-				
Call Control	2.6.2.1			No.				
				PS Name	PROFILE_NAME_PSy	4.6.2		
				Line No. 1-2				
				Phone Number	PHONE_NUMBER_PSy_n	4.6.2		
					CW_ENABLE_PSy_n	4.6.1		
					RETURN_VOL_SET_DEFAULT_ENABLE	4.6.1		
[PS select screen]				-				
PS Name	2.6.3.1			PS Name	PROFILE_NAME_PSy	4.6.2		
Call Control	2.6.3.2			Default Line for Outgoing	DEFAULT_LINE_SELECT_PSy	4.4.1		
Dial Plan	2.6.3.3			Dial Plan (max 500 columns)	DIAL_PLAN_PSy	4.6.1		
				Call Even if Dial Plan Does Not Match	DIAL_PLAN_NOT_MATCH_ENABLE_PSy	4.6.1		
[Line select screen]				-				
PS Name	2.6.4.1			PS Name	PROFILE_NAME_PSy	4.6.2		
Phone Number	2.6.4.2			Phone Number	PHONE_NUMBER_PSy_n	4.6.2		
Call Control	2.6.4.3			Display Name	DISPLAY_NAME_PSy_n	4.6.1		
				Voice Mail Access Number	VM_NUMBER_PSy_n	4.6.1		
				Enable Shared Call	SHARED_CALL_ENABLE_PSy_n	4.6.1		
				Synchronize Do Not Disturb and Call Forward	FWD_DND_SYNCHRO_ENABLE_PSy_n	4.6.1		
Call Features	2.6.4.4			Block Caller ID				
				Block Anonymous Call				
				Do Not Disturb				
Call Forward	2.6.4.5	Unconditional						
		Enable Call Forward						
		Phone Number						
		Busy						
		Enable Call Forward						
		Phone Number						
		No Answer						
Enable Call Forward								
Phone Number								
		Ring Count						

WEB Settings				Configuration File			
Menu Item	Section Title	Chapter number(*2)	Parameter in the Web Setting	Parameter in a Configuration File	Chapter number(*3)		
Telephone	Button Settings	[PS tab screen]	-				
		Button Settings	2.6.5.1	No. PS Name Phone Number	PROFILE_NAME_PSy PHONE_NUMBER_PSy_n	4.6.2 4.6.2	
		[PS select screen]		-			
		PS Name	2.6.6.1	PS Name	PROFILE_NAME_PSy	4.6.2	
		Flexible Button Settings	2.6.6.2	No.			
				Type (No. 1-12)	FLEX_BUTTON_FACILITY_ACTx_PSy	4.4.5	
				Parameter (No. 1-12)	FLEX_BUTTON_FACILITY_ARGx_PSy	4.4.5	
				Label Name (No. 1-12)	FLEX_BUTTON_QUICK_DIALx_PSy FLEX_BUTTON_LABELx_PSy	4.4.5 4.4.5	
		[Copy & Paste select screen]		-			
		Copy Source PS Name	2.6.7.1	PS Name	PROFILE_NAME_PSy	4.6.2	
		Copy Source Flexible Button Settings	2.6.7.2	No.			
				Type (No. 1-12)	FLEX_BUTTON_FACILITY_ACTx_PSy	4.4.5	
				Parameter (No. 1-12)	FLEX_BUTTON_FACILITY_ARGx_PSy	4.4.5	
				Label Name (No. 1-12)	FLEX_BUTTON_QUICK_DIALx_PSy FLEX_BUTTON_LABELx_PSy	4.4.5 4.4.5	
		Tone Settings	Dial Tone	2.6.8.1	Tone Frequencies	DIAL_TONE1_FRQ	4.4.2
					Tone Timings	DIAL_TONE1_TIMING	4.4.2
						DIAL_TONE1_GAIN	4.4.2
						DIAL_TONE1_RPT	4.4.2
						DIAL_TONE2_FRQ	4.4.2
						DIAL_TONE2_GAIN	4.4.2
						DIAL_TONE2_RPT	4.4.2
						DIAL_TONE2_TIMING	4.4.2
	Busy Tone		2.6.8.2	Tone Frequencies	BUSY_TONE_FRQ	4.4.2	
				Tone Timings	BUSY_TONE_TIMING	4.4.2	
					BUSY_TONE_GAIN BUSY_TONE_RPT	4.4.2 4.4.2	
	Ringing Tone		2.6.8.3	Tone Frequencies	RINGBACK_TONE_FRQ	4.4.2	
				Tone Timings	RINGBACK_TONE_TIMING	4.4.2	
					RINGBACK_TONE_GAIN RINGBACK_TONE_RPT	4.4.2 4.4.2	
	Stutter Tone		2.6.8.4	Tone Frequencies	DIAL_TONE4_FRQ	4.4.2	
				Tone Timings	DIAL_TONE4_TIMING	4.4.2	
					DIAL_TONE4_GAIN DIAL_TONE4_RPT	4.4.2 4.4.2	
	Reorder Tone		2.6.8.5	Tone Frequencies	REORDER_TONE_FRQ	4.4.2	
				Tone Timings	REORDER_TONE_TIMING	4.4.2	
					REORDER_TONE_GAIN REORDER_TONE_RPT	4.4.2 4.4.2	
	Hold Tone		-		HOLD_TONE_FRQ	4.4.2	
					HOLD_TONE_GAIN	4.4.2	
	Other settings		-		BELL_CORE_PATTERN1_TIMING	4.4.2	
					BELL_CORE_PATTERN2_TIMING	4.4.2	
					BELL_CORE_PATTERN3_TIMING	4.4.2	
					BELL_CORE_PATTERN4_TIMING	4.4.2	
					BELL_CORE_PATTERN5_TIMING	4.4.2	
	Telephone Settings		Telephone Settings	2.6.9.1	Number Matching Lower Digit	NUMBER_MATCHING_LOWER_DIGIT	4.4.3
					Number Matching Upper Digit	NUMBER_MATCHING_UPPER_DIGIT	4.4.3
						DEFAULT_LANGUAGE	4.4.3
						POUND_KEY_DELIMITER_ENABLE	4.4.3
						FLEXIBLE_KEY_LIST_DISPLAY_TIMER	4.4.3
	Import Phonebook	[All tab screen]		-			
		Import Mode	2.6.10.1	Mode Select			
		Import Time Setting	2.6.10.2	Date			
				Date			
				Month			
				Year			
				Time			
		Hour					
		Minute					
		Import Phonebook	2.6.10.3	File Name			
		[PS tab screen]		-			
		Import Phonebook	2.6.11.1	No. PS Name Phone Number	PROFILE_NAME_PSy PHONE_NUMBER_PSy_n	4.6.2 4.6.2	
				[PS select screen]		-	
	PS Name	2.6.12.1	PS Name	PROFILE_NAME_PSy	4.6.2		
	Import Phonebook	2.6.12.2	File Name				
	Export Phonebook	[PS tab screen]		-			
		[PS tab screen]	2.6.13.1	PS Name Phone Number	PROFILE_NAME_PSy PHONE_NUMBER_PSy_n	4.6.2 4.6.2	

WEB Settings				Configuration File			
	Menu Item	Section Title	Chapter number(*2)	Parameter in the Web Setting	Parameter in a Configuration File	Chapter number(*3)	
Maintenance	Firmware Maintenance	Firmware Maintenance	2.7.1.1	Enable Firmware Update	FIRM_UPGRADE_ENABLE	4.2.4	
				Firmware File URL	FIRM_FILE_PATH	4.2.4	
				PS Update Type	PS_FIRM_UPGRADE_AUTO	4.2.4	
					FIRM_VERSION	4.2.4	
					PS_FIRM_UPGRADE_MODE	4.2.6	
	All Firmware Update	Update Mode		2.7.2.1	Mode		
					Date		
		Update Time Setting		2.7.2.2	Date		
					Month		
					Year		
					Time		
					Hour		
					Minute		
		Update Firmware		2.7.2.3	Encryption		
					File Name		
	Provisioning Maintenance	Provisioning Maintenance	2.7.3.1		OPTION66_ENABLE	4.2.5	
					OPTION66_REBOOT	4.2.5	
				Enable Provisioning	PROVISION_ENABLE	4.2.5	
				Standard File URL	CFG_STANDARD_FILE_PATH	4.2.5	
				Product File URL	CFG_PRODUCT_FILE_PATH	4.2.5	
				Master File URL	CFG_MASTER_FILE_PATH	4.2.5	
				System File URL	CFG_SYSTEM_FILE_PATH	4.2.5	
				Cyclic Auto Resync	CFG_CYCLIC	4.2.5	
				Resync Interval	CFG_CYCLIC_INTVL	4.2.5	
				Header Value for Resync Event	CFG_RESYNC_FROM_SIP	4.2.5	
					CFG_FILE_KEY1	4.2.5	
					CFG_FILE_KEY2	4.2.5	
				CFG_FILE_KEY3	4.2.5		
				CFG_FILE_KEY4	4.2.5		
				CFG_FILE_KEY_LENGTH	4.2.5		
				CFG_RTRY_INTVL	4.2.5		
				CFG_RESYNC_TIME	4.2.5		
				PROVISION_SUPERMASTER_ONLY	4.2.6		
Restart				Restart	2.7.4		
Other settings	Syslog Settings	Syslog Settings			SYSLOG_EVENT_SIP	4.2.3	
					SYSLOG_EVENT_CFG	4.2.3	
					SYSLOG_EVENT_VOIP	4.2.3	
					SYSLOG_EVENT_TEL	4.2.3	
					SYSLOG_ADDR	4.2.3	
					SYSLOG_PORT	4.2.3	
					SYSLOG_RTSMPLY_INTVL	4.2.3	