

SYSLOG from Phone

(KX-UT1xx series/248)

No. 15-006

May 25 , 2012

Ver.1.1

Panasonic Corporation

Abstract about this document

This document describes about how to send SYSLOG from phone to SYSLOG server.

Revision history

| Date | Version | Revision | Firmware version |
|---------------|----------|----------------------------------|------------------|
| Jun. 22, 2011 | Ver. 1.0 | Initial Release | All versions |
| May 25, 2012 | Ver. 1.1 | Correct misdescription/Add UT248 | All versions |


Outline

- 1) Explanation about overview of SYSLOG. Format
- 2) Explanation about type and priority of configuration files
- 3) Configuration of SYLOG.

About SYSLOG

UT1xx series is supporting SYSLOG and SYSLOG is standard for logging messages.

We can provide several type of information by SYSLOG.



Information Class sent thru SYSLOG

- SIP Message information
- File Download information
- VoIP information

Example of SYSLOG (VoIP information)

```
<11>Jul 22 18:29:30 0080F0ABCDEF [SIP][Line-1:0123456789]Registration Success
```

```
<11>Jul 22 18:30:30 0080F0ABCDEF [SIP][Line-1:0123456789]Registration failure by no response
```

SYSLOG Format and Information class

SYSLOG Packet format

| Priority part | Header part | Message part |
|--|----------------------------------|-------------------------------------|
| -Priority -Information Class (Type) | -Time Stamp -Host Information | -Detailed message based on the type |

SYSLOG Packet information class with priority

| Information | Class | Priority | Description |
|---------------|-------|----------------|---|
| SIP Message | SIP | Error (3) | Success / Failure REGISTER |
| | | information(6) | All SIP message sent / received |
| File Download | FDL | warning(4) | Failure of downloading Configuration file or Firmware |
| | | information(6) | Case the response value of Configuration file and Firmware is 302 |
| | | | Success of downloading Configuration file or Firmware |
| VoIP info | VIP | information(6) | RTCP information |

Detailed message for each Class (SIP)

Message information

| Priority | Generate Timing | Message Format |
|-------------|---|---|
| Error | Generated when status is changed before and after REGISTER. | [SIP][Line-n: <i>Phone Number</i>]Registration {Success end failure by {(NNN) no response DNS error internal error} Where n is Line number and (NNN) is Response code from Server. |
| Information | Export all information Received / Sent SIP messages | [SIP][SEND RECV]: Src=<IP ADDR>:<PORT> Dst=<IP ADDR>:<PORT> <SIP message full> |

Example :

```
<11>Jul 22 18:29:30 0080F0ABCDEF [SIP][Line-1:0123456789]Registration Success
```

```
<11>Jul 22 18:30:30 0080F0ABCDEF [SIP][Line-1:0123456789]Registration failure by no response
```

Detailed of each SYSLOG format (File Download)

Message information

| Priority | Generate Timing | Message Format |
|-------------|---|--|
| Warning | Generate when failed of file transfer. | [FDL]File transfer failure by XXX. URL={URL+File Name} Where XXX is Error Information |
| Information | Generate when beginning or completion of file transfer by normally. | [FDL]File {download upload} start. URL={URL+File Name} or {Configuration Firmware Phonebook} file {download upload} start. |
| | | [FDL]File {download upload} complete. URL={URL+File Name} |

Example :

```
<14>Jul 22 18:29:30 0080F0ABCDEF [FDL]File download start. URL=http://www.test.com/0080F0ABCDEF.cfg
<12>Jul 22 18:29:40 0080F0ABCDEF [FDL]File transfer failure by Error Response from Server (403). URL=http://www.test.com/0080F0ABCDEF.cfg
<14>Jul 22 18:30:30 0080F0ABCDEF [FDL]Firmware file download start. URL=http://www.test.com/0080F0ABCDEF.cfg
<12>Jul 22 18:32:00 0080F0ABCDEF [FDL]File transfer failure by Version Error. URL=http://www.test.com/0080F0ABCDEF.cfg
<14>Jul 22 18:33:30 0080F0ABCDEF [FDL]Phonebook file upload start.
<14>Jul 22 18:34:30 0080F0ABCDEF [FDL]File transfer complete. URL=http://www.test.com/0080F0ABCDEF.cfg
```

Detailed of each SYSLOG format (VoIP)

Message information

| Priority | Generate Timing | Message Format |
|-------------|--|--|
| Information | Generate RTP summery information Periodically or Finishing of one call | [VIP]Ch ID:N1 Packets sent:N2 Packets received:N3 Received packets discarded:N4 Received packets lost:N5 |

Included information:

- Count of sent RTP packets
Total of RTP data packets that UT1xx/248 sent.
- Count of received RTP packets
Total of RTP data packets that UT1xx/248 received.
- Count of discarded RTP packets
Total of RTP data packets that UT1xx/248 discarded.
UT1xx series has jitter buffer. A jitter buffer temporarily stores arriving packets in order to delay variations. If RTP packets arrive too late then are discarded.
- Count of lost RTP packets
Total of lost RTP data packets on network.

Example:

```
<14>Jul 22 18:29:30 0080F0ABCDEF [VIP]Ch ID:4 Packets sent:100 Packets received:100 Received packets discard
```

How to set SYSLOG

Please add following setting in case you'd like to monitor provisioning (downloading configuration file) status. You can see detailed information about each parameter in next page.

- **SYSLOG_ADDR**: Specifies the IP address or FQDN of the SYSLOG server.
- **SYSLOG_PORT**: Specifies the port number of the SYSLOG server.
- **SYSLOG_EVENT_SIP***1: Logs SIP-related SYSLOG events.
- **SYSLOG_EVENT_CFG***1: Logs SYSLOG events regarding configuration.
 "6" is for download (provisioning) status.
- **SYSLOG_EVENT_VOIP***1: Logs SYSLOG events regarding VoIP operation.
- **SYSLOG_EVENT_TEL***1: Logs SYSLOG events regarding telephone functions.

Example:

```
## SYSLOG Settings  
SYSLOG_EVENT_CFG="6"  
SYSLOG_ADDR="192.168.1.51"  
SYSLOG_PORT="514"
```

Note : Even though you don't have SYSLOG Server, we can capture the packet for SYSLOG by wireshark.

Explanation of each parameter

SYSLOG_EVENT_SIP

| | |
|----------------------|---|
| Value Format | Integer |
| Description | Specifies which SIP-related syslog events are sent to the syslog server. Note <ul style="list-style-type: none">• If the level of the event is higher than or equal to the set value, the log is sent to the syslog server. |
| Value Range | 0–6 <ul style="list-style-type: none">– 0: no logs sent– 1: emergency (highest)– 2: alert– 3: critical– 4: error– 5: warning– 6: information (lowest) |
| Default Value | 0 |

SYSLOG_EVENT_CFG

| | |
|----------------------|---|
| Value Format | Integer |
| Description | Specifies the threshold of syslog events regarding configuration. |
| Value Range | 0–6 |
| Default Value | 0 |

SYSLOG_EVENT_VOIP

| | |
|----------------------|--|
| Value Format | Integer |
| Description | Specifies the threshold of syslog events regarding VoIP operation. |
| Value Range | 0–6 |
| Default Value | 0 |

SYSLOG_EVENT_TEL

| | |
|----------------------|---|
| Value Format | Integer |
| Description | Specifies the threshold of syslog events regarding telephone functions. Note <ul style="list-style-type: none">• This setting is not applicable for the current version. No logs will be sent to the syslog server, even if values "1–6" are specified. |
| Value Range | 0–6 |
| Default Value | 0 |

SYSLOG_ADDR

| | |
|----------------------|---|
| Value Format | String |
| Description | Specifies the IP address or FQDN of the syslog server. |
| Value Range | Max. 127 characters (IP address in dotted-decimal notation or FQDN) |
| Default Value | Empty string |

SYSLOG_PORT

| | |
|----------------------|---|
| Value Format | Integer |
| Description | Specifies the port number of the syslog server. |
| Value Range | 1–65535 |
| Default Value | 514 |

SYSLOG_RTPSMLY_INTVL_n

| | |
|-------------------------------|---|
| Parameter Name Example | SYSLOG_RTPSMLY_INTVL_1, SYSLOG_RTPSMLY_INTVL_2, ..., SYSLOG_RTPSMLY_INTVL_6 |
| Value Format | Integer |
| Description | Specifies the interval, in seconds, to send summarized information of RTP packets to the syslog server. |
| Value Range | 0, 5–65535 (0: No information sent) |
| Default Value | 20 |