

How to download and install the device driver (STI driver) for the Panasonic document scanner

Copyright© 2003-2008, Panasonic Communications Co., Ltd., All rights reserved.

Target model	Target OS
KV-S1020C / KV-S1025C KV-S2026C(U) / KV-S2028C KV-S2046C(U) / KV-S2048C KV-S7065C KV-S7075C KV-S3065CL / KV-S3065CW KV-S4065CL / KV-S4065CW KV-S4085CL / KV-S4085CW KV-S3085 KV-S3105C	Windows® 2000 Windows® XP Windows Vista® 32bit Edition Windows Vista® 64bit Edition

Note

- Make sure to log in as an administrator while installing.

■ How to download and install the driver

- 1 Download the file (panascan***.exe) into an appropriate folder in your computer.
(“***” part of the filename stands for version number)

After the installation has been completed, you may remove the downloaded file.

- 2 Turn off the power of the scanner, if it is connected to your computer.
- 3 Run the downloaded file (panascan***.exe) using explorer (Depending on the configuration of your computer, “.exe” part of the filename may not be displayed)
- 4 Follow the instructions on the screen.

Even if the screen ‘Windows can’t verify the publisher of this driver software’ appears, continue installation.

- 5 Connect the scanner and turn on the power. (For SCSI connection, restart your computer.)
- 6 Follow the instructions of the hardware wizard to complete the installation.

Even if the screen ‘Digital Signature was not found for this driver’ or ‘has not passed Windows Logo testing...’ appears, continue installation.

- Windows® 2000 is Microsoft® Windows® 2000 operating system.
- Windows® XP is Microsoft® Windows® XP operating system.
- Windows Vista® is Microsoft® Windows Vista® operating system.
- Microsoft, Windows and Windows Vista are registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.